



How to wire to the M30 inputs

Details and diagrams explaining how to wire the M30 can be found in the Installation guide supplied with the M30 on CD/DVD. Below is a quick explanation on how to wire to the M30 Inputs/Sensors.



Remember you must set the appropriate DIL switch for each of the M30 inputs, to either Normally Open (NO) or Normally Closed (NC), depending upon the input type connected.

Important

Under NO circumstances should any Voltage be connected to the M30 Switched Inputs.